USER'S MANUAL
810 LX / 815 LX



LANCER

advanced washing & disinfection solutions

PRECAUTIONS TO BE TAKEN BEFORE USE

- Users must be trained before using the washer.

- The staff that use or repair this washer must have followed a complete training referring its use and maintenance. This training must include the selection and understanding of the washing cycle, the loading and unloading of the baskets and the handling of the washing products.

- The staff in contact with the detergent products and its emanations, which could be used in this washer, must have knowledge of the safety data sheet of the used products as well as the detailed instructions about the dangers and the detection of toxic product leaks.

- The training of the users and technicians must be done regularly and always before the first use of the washer. A written register of these trainings must be kept in order to prove the presence and the understanding of the interested parties.

SUMMARY

SUMMARY 5

CHAPTER 1 INTRODUCTION.....9

1. 810 LX / 815 LX RANGE 10

2. USER'S MANUAL 11

CHAPTER 2 BEFORE YOU START 13

1. SAFETY ADVICES 14

1.1 PRECAUTIONS FOR USE 14

1.2 USE 15

2. OPENING THE WASHER'S DOOR 16

3. WASHING PRODUCTS 17

3.1 WASHING PRODUCTS CATEGORIES 17

3.2 INSTRUCTIONS TO RESPECT IN CASE OF HANDLING THE WASHING PRODUCTS 17

3.3 INSTRUCTIONS TO RESPECT IN CASE OF CHANGING THE PRODUCT FORMULA 18

3.4 CHANGE OF THE TANKS 18

4. EXTERNAL PRINTER (OPTION) 19

4.1 CHECKING THE PRINTER 19

4.2 CHOICE OF THE SUITABLE PAPER ROLLS 19

4.3 REMOVING PAPER AND CLEARING PAPER JAMS 19

4.4 LOADING PAPER 19

4.5 OPERATING MODES 20

4.6 PRINTER MAINTENANCE 20

5. USING OF THE ACCESSORIES 21

5.1 SOME EXAMPLES 21

5.2 FITTING THE BASKETS 23

CHAPTER 3 WASHING CYCLE LAUNCHING..... 25

1. DESCRIPTION AND BASIC FUNCTIONS OF KEYPAD 26

2. LAUNCHING OF A CYCLE 27

2.1 SWITCHING ON 27

2.2 CYCLES 27

2.3 LAUNCHING THE CYCLE 29

2.4 INFORMATION AVAILABLE DURING THE WASH CYCLE 31

3. END OF CYCLE 32

3.1 OPENING OF THE DOORS 32

3.2 OPENING 32

3.3 REPRINTING OF THE TICKET 33

3.4 SWITCHING OFF 33

4. ACCESS TO USER MENU 34

4.1 MODIFYING THE WASHING CYCLES 35

4.2 SEQUENCES READING OF ONE WASHING CYCLE 41

4.3 DOSING PUMP PRIMING 42

4.4 NAME CHOICE OF ONE WASHING CYCLE 43

4.5 THE CHOICE OF MACHINE NAME 44

4.6 READING OF CYCLE FAULTS 45

4.7 PRINTER PARAMETERS (OPTION) 46

4.8 RETURN TO THE INITIAL STATE 46

5. TABLE OF FACTORY-PROGRAMMED CYCLES – 810 LX 47

6. TABLE OF FACTORY-PROGRAMMED CYCLES - 815LX 48

CHAPTER 4 TRACEABILITY 49

1. EXTERNAL PRINTER (OPTION) 50

CHAPTER 5 MAINTENANCE OF THE WASHER 51

1. FILTERS 52

1.1 STRAINERS FILTERS 52

1.2 CHAMBER FILTERS 52

2. SHUT DOWN AT END OF DAY 52

3. EXTERNAL MAINTENANCE OF THE WASHER 53

3.1 CLEANING METHOD 53

3.2 CLEANING PRODUCTS 53

4. DECONTAMINATION OF THE MACHINE AND PARTS 54

4.1 WHEN TO DECONTAMINATE THE WASHER ? 54

4.2 HOW TO DECONTAMINATE THE MACHINE ? 55

5. PREVENTIVE MAINTENANCE 55

6. PREVENTATIVE MAINTENANCE SCHEDULE 56

7. RECOMMENDED SPARE PARTS 810 LX – 815 LX 57

CHAPTER 6 PROBLEMS 59

1. INCIDENTS 60

1.1 THE DETERGENT OR NEUTRALIZING AGENT DOES NOT ENTER THE WASHER 60

1.2 THE WASHER DOES NOT FUNCTION 60

1.3 ABNORMAL NOISE 60

2. WARNINGS 61

2.1 - LACK OF PRODUCTS 61

2.2 HOT CHAMBER 61

2.3 FULL BASIN 61

2.4 MAINTENANCE REMINDER 62

2.5 PREVENTATIVE MAINTENANCE REQUIRED 62

3. FAULT ALARMS 63

3.1 FAULT N°1 PROBE FAULT. 63

3.2 FAULT N°2 EMPTYING FAULT. 63

3.3 FAULT N°3 HEATING EXCESS. 64

3.4 FAULT N°4 HEATING FAULT. 64

3.5 FAULT N°5 NO WATER. 65

3.6 FAULT N°6 DOOR FAULT 65

3.7 FAULT N°7 LEVEL FAULT. 66

3.8 FAULT N°8 PRESSURESTAT FAULT. 66

CHAPTER 1 INTRODUCTION

You have in your possession a LANCER washer.

Its good working and your entire satisfaction depend on the attention you pay when reading this guide.

You will find here some advices about the use, the loading and the maintenance. Follow them, as they have been written in your interest.

Before using your washer, learn to know it and use it rightly, so as to it can develop its tasks many years.

1. 810 LX / 815 LX RANGE

810 LX / 815 LX washers-dryers belongs to the LABEXIA range of washers and washer-driers for the cleaning and drying of labware in the chemistry, microbiology, quality control and analytical laboratories.

Fully programmable, easy to use, 810 LX/ 815 features the automatic electric door locking for the users comfort and safety.

Some of the main features of 810 LX / 815LX washers:

- Microprocessor control, with 4 pre-set programs featuring programmable parameters
- Easy loading and unloading thanks to the ergonomic loading level (plinth option), the extractable runners for the baskets and the automatic electric door lock.

This washer has been developed and manufactured following the standards (CE or UL).

For the washers in conformity with the CE standards, a “CE conformity declaration” is delivered with the machines.

2.USER'S MANUAL

The present manual is destined to facilitate the operations of use, handle, maintenance and repair.

This only concerns the operations to be done by an owner of code user.

Before using your washer and in order to obtain the best service read carefully the following advices and recommendations. Follow them, as they have been written in your interest.

Respecting the precautionary measures of use, the washer must only be used for the washing operations described in the manual.

This manual is divided in 6 chapters, completed by an appendix.

You have just ended the reading of **chapter 1.**

Chapter 2 will familiarise yourself with your washer in order to use it as correct as possible.

Chapter 3 describes step by step the washing process, of launching a cycle at the end of this one.

Chapter 4 introduces the different traceability systems available in the LABEXIA LX range washers-dryers.

Chapter 5 describes the operations of internal and external maintenance of your washer in order to keep it in good state as long possible.

Chapter 6 is a description of the different working incidents that you could find when using your washer.

In **Appendix** you will find the safety data sheet of the LANCER washing products.

All over this manual, we have incorporated brief comments and icons to help you locate the important information.

When you see this icon, it means:

: ATTENTION ! ! PAY SPECIAL ATTENTION ! !

CHAPTER 2 BEFORE YOU START

After having installed rightly your washer, following the installation manual, you can begin to familiarise with this one.

You will find in this chapter all the information of indispensable knowledge to assure the good working and avoid material and corporal damage.

1.SAFETY ADVICES

This apparatus, dedicated to an industrial use, has been developed to wash and dry glassware, labware in the chemistry, microbiology, quality control and analytical laboratories …

This washer must be used under the normal conditions of operation in conformity with the instructions manual of the manufacturer
We decline any responsibility and guarantee in the event of non-respect of these recommendations which can involve body or material damages

- use only products of washing and cleaning certified for employment with washers of laboratory glassware.
- if before washing, you treat your material of laboratory using solvents and in general, all produced flammable or with strong detonating capacity, do not introduce immediately it into the chamber of the apparatus.
- In the same way, it is strongly recommended not to use solvents or aerosols near the apparatus.
- If incidents occur and you cannot solve them using solutions that we recommend you, do not hesitate to contact Lancer's technical assistance service.

1.1 PRECAUTIONS FOR USE

TEMP. > 60°C

(D) NICHT WÄHREND DEM SPÜLGANG ÖFFNEN
(F) NE PAS OUVRIR EN FONCTIONNEMENT
(GB) DO NOT OPEN WHEN FUNCTIONING
(NL) NIET OPENEN TIJDENS PROCES

It is strictly prohibited to use the washer in an explosive environment or to use solvents, hydrocarbons, nitric acid, alcohol, alcohol derivatives, or other flammable products in the machine.

SAFETY GLASSES OBLIGATORY

SAFETY GLOVES OBLIGATORY

Risk for operator depends on the products (detergents and acids) used inside the machine and on the nature of deposit on washing items.

Wearing safety glasses and gloves must not be sufficient in some cases.

Operator has to read safety data sheets of used products (delivered with the washer) so as to prevent risk before opening the door.

1.2 USE

DO NOT FORCE DOOR LOCKING DEVICE DURING A WASHING CYCLE

This machine uses detergent (caustic) and acid additives with elevated (95°C) temperatures in the chamber during the different phases of the wash cycle. Opening the door during the wash cycle can cause **EXPOSURE TO HIGH TEMPERATURES AND HAZARDOUS CHEMICALS AND VAPORS**.

WASH CYCLE INTERRUPTED BY OPENED DOOR

If the wash chamber door is opened during the wash, the wash cycle is stopped and is considered unsuccessful. The machine will return to its initial state. The wash cycle should be restarted using the steps contained in this manual

WASH CYCLE INTERRUPTED BY ALARM CONDITION

If the machine goes into an alarm condition, the wash cycle is stopped and is considered unsuccessful. The machine will return to its initial state. Resolve the problem then restart the cycle

2.OPENING THE WASHER'S DOOR



Pull the handle and lower the door to the horizontal position.

At start of cycle, door is automatically locked.

If a "CYCLE ALARM" occurs, unlock the door by pressing on button then open the door.

At end of cycle, wait few seconds to allow door unlocking then open the door

Do not force to open the door during a washing cycle, door safety locking device can be damaged.

Do not climb or sit on the door.
Maximum weight allowed on the door is 35 kg.

3.WASHING PRODUCTS

THE PROGRAMS PREESTABLISHED WITH THIS WASHER HAVE BEEN VALIDATED WITH THE LANCER WASHING PRODUCTS.

3.1 WASHING PRODUCTS CATEGORIES

NON-FOAMING DETERGENT

Using the correct non-foaming detergent is required for proper cleaning in this machine. The non-foaming detergent must be matched to remove the contamination source in order to ensure satisfactory washing.
IT IS STRICTLY PROHIBITED TO USE SOLVENTS AS DETERGENT.
PLEASE REFER TO SUPPLIERS MATERIAL SAFETY DATA SHEET FOR SPECIFIC SAFETY AND FORMULATION INFORMATION REGARDING THE DETERGENT USED IN THIS EQUIPMENT.
THE PROGRAMMED CYCLES ON THIS WASHER HAVE BEEN VALIDATED WITH LANCER CHEMICALS.

NEUTRALIZING ACID

Using the correct non-foaming neutralizing acid is required for proper cleaning in this machine. The non-foaming neutralizing acid must be matched to remove the detergent source in order to ensure satisfactory washing.
THE USE OF NITRIC ACID IS PROHIBITED. ONLY DILUTE PHOSPHORIC, ACETIC AND CITRIC ACIDS CAN BE USED.
PLEASE REFER TO SUPPLIERS MATERIAL SAFETY DATA SHEET FOR SPECIFIC SAFETY AND FORMULATION INFORMATION REGARDING THE ACID USED IN THIS EQUIPMENT.
THE PROGRAMMED CYCLES ON THIS WASHER HAVE BEEN VALIDATED WITH LANCER CHEMICALS.

3.2 INSTRUCTIONS TO RESPECT IN CASE OF HANDLING THE WASHING PRODUCTS

ANYBODY CALLED TO HANDLE THE WASHING PRODUCTS MUST BE INFORMED OF THE IMPLICATED RISKS TO THESE PRODUCTS.

3.3 INSTRUCTIONS TO RESPECT IN CASE OF CHANGING THE PRODUCT FORMULA

Before changing to a different type or brand of cleaning chemical (acid or detergent) it is necessary to rinse the plumbing circuitry of the machine. Install the new chemical(s) per the installation instructions and then prime the detergent and acid pumps. Then a wash cycle can be programmed and run which uses several rinses with water only. This will prevent any cross contamination of chemicals.

After the new cleaning chemical have been installed, it will be necessary to adjust the chemical dosing times in all applicable steps of the wash cycle in order to match the formulation of the new cleaning chemicals.

Please contact LANCER for advice or assistance.

3.4 CHANGE OF THE TANKS

Before launching the cycle, check product tank levels and change those with low levels so as to avoid bad washing because of a lack of additive.

WHEN TO CHANGE THE CHEMICAL CONTAINERS

This message is displayed when the chemical bottles are almost empty.

W A R N I N G
L A C K O F C H E M I C .

It is necessary to fill or change the detergent or acid containers to continue the cycle.

HOW TO CHANGE THE CHEMICAL CONTAINERS ?

Press ⏻ button to switch off the washer.
Use the necessary protection for the chemical to be changed (gloves, mask, safety glasses…) .
Locate the container(s) that need to be changed.
Unscrew the cap(s) from the empty chemical bottle(s) and take out the chemical suction tube(s).
Unscrew the cap(s) from the full chemical bottle(s) and insert the chemical suction tube(s). Tighten the cap(s) to secure the chemical suction tube in place.
Press ⏻ button to switch the washer on.
Dispose of used chemical bottles or caps according to local and company regulations. Please consult the Material Safety Data Sheet for specific information regarding the chemicals used in the washer.

4.EXTERNAL PRINTER (OPTION)

4.1 CHECKING THE PRINTER

Before launching any cycle or reprinting the printout, check the quantity of paper of the printer roller.

4.2 CHOICE OF THE SUITABLE PAPER ROLLS

Please use quality paper. The use of non-approved products can cause dust and increased wear. This can affect the guarantee. The paper roll is normally delivered separately in order to prevent it from unrolling or becoming damaged during transport. Consult Lancer about suitable paper rolls.

4.3 REMOVING PAPER AND CLEARING PAPER JAMS

If there is some paper in the printer when a new roll is necessary or a paper jam has occurred, simply open the cover and press the paper advance button.

4.4 LOADING PAPER

1. Slide the cover opening button forward until it opens.

2. Unroll a small amount of paper and insert the paper roll in the printer.

3. Close the cover, the paper has been loaded.



Pressing on the paper advance button while the printer is on standby mode makes the paper advance. However, the advance button has several other functions:

⇨Pressing the button once and releasing it:

- In standby mode, makes the paper advance.
- In sleep mode, makes the printer go into the standby mode.

⇨In standby mode, a “double click” on the button•, prints out a sample message.

4.5 OPERATING MODES

"Stand-by mode": ready to receive data but there is no data waiting to be printed out in the buffer and the printer engine is not turning.

"Sleep mode": actually disabled. If the paper advance button is pressed, the external charger connected or external data is received, the printer leaves sleep mode and enters stand-by mode. The LED is off in sleep mode.

There is no switch. Powering up is automatic or carried out by a command received from the washer-disinfector. To save energy, the printer enters sleep mode after a period of inactivity. The printer can be also programmed to always remain active or to enter sleep mode on command.

4.6 PRINTER MAINTENANCE

After a certain time of use, it may prove necessary to remove paper dust from inside and around the mechanism. Use a small vacuum for cleaning.

5. USING OF THE ACCESSORIES

IF THE LOADINGS TO BE HANDLED ARE SUPERIOR TO 25 KG THERE IS PLACE TO USE A HANDLING SYSTEM.

5.1 SOME EXAMPLES

In order to wash items in "**TE**" or "**TH**" type baskets, place the baskets on the "**PS**" (basic rack) or "**PSB**" (basic rack with spray arm) after removing one or more "**GS**" (support grilles). Check that the basket is correctly fitted on the rods of the rack designed for that purpose. Reinstall the grilles for any washing operation that does not require the use of "**TE**" or "**TH**" type baskets.



Note : The "**PS**" should only be positioned at the bottom level of the washer chamber where washing action is provided by the lower spray arm. The "**PSB**" can be positioned on any level.

It is extremely important that the items to be washed are prevented from moving in order to obtain correct cleaning and to avoid breakage of fragile items. Items that can be easily moved or knocked over when loaded on the "**PS**" or "**PSB**" rack should be secured in place. The "**GC**" hold down screen should be used for "**PS**" or "**PSB**" racks. The "**GCI**" hold down screen should be used for injector racks.







In the case of washing items with small diameter openings such as volumetric flasks, it is very important that the flow rate of the injectors used must be lower than the flow capacity of the flasks to be washed in order to avoid a gradual filling of the flasks during the washing cycle. If the diameter of the opening is too small to allow the water to escape from around the injector the mechanical action of the injector can be absorbed by the water contained in the glassware giving poor cleaning results. It is imperative to use baskets with injectors of proper diameter and, above all, to secure lightweight items with a "**GC**" or "**GCI**" hold down screen.

In order to wash items on a "**PL**" type basket (for cleaning slides), place the baskets on the "**PS**" (basic rack) or "**PSB**" (basic rack with spray arm) after removing one or more "**GS**" (support grilles). Check that the basket is correctly fitted on the rods of the rack designed for that purpose. Reinstall the grilles for any washing operation that does not require the use of "**PL**" type baskets.



You should only use baskets that are suitable for the parts to be washed. When your washer is put into service, our technicians will give you useful advice on the best way to load the racks relative to the items to be washed.

Please feel free to contact LANCER for advice or assistance.

When several racks are used simultaneously on the different levels, only one rack should be pulled out of chamber on the door and the runners at a time.

5.2 FITTING THE BASKETS



1-2-3 BASKET WHEELS
4 PIN

a) Pull the slide rails out of the chamber.

b) Remove the front pins.

c) Insert wheels 1 and 2 of the basket in the slide rails.

d) Fit the pins back in place between wheels 2 and 3.

The choice of the baskets and racks is very important to efficient cleaning.
Please feel free to contact LANCER for advice or assistance.

CHAPTER 3 WASHING CYCLE LAUNCHING

This chapter has been made to enable to function your washer.

You will get the launching procedure of a washing cycle and the manipulations to do at the start and the end of cycle.

1.DESCRIPTION AND BASIC FUNCTIONS OF KEYPAD



Legend :

1	**START**" BUTTON
2	ENTER BUTTON (FOR PROGRAMMING) / DOOR UNLOCK
3	WASHER POWER ON/OFF BUTTON
4	BUTTON 3 **/** "**-**" FUNCTION BUTTON
5	BUTTON 4 / "**+**" FUNCTION BUTTON
6	LIQUID CRYSTAL DISPLAY UNIT
7	BUTTON 1
8	BUTTON 2

2.LAUNCHING OF A CYCLE

BEFORE START, VERIFY THAT THE TAPS OF ENTRANCE OF WATER ARE OPENED.

2.1 SWITCHING ON

Push the key ⏻.
The display indicates the number of the last executed program and the type of washer.

P R O G R A M N ° 0 4
L A N C E R

If the previous cycle has been stopped before the end, the display indicates :

W A R N I N G
F A U L T Y C Y C L E

Press START to return to the initial state.

2.2 CYCLES

The washer is delivered with 4 pre-established programs at the factory (see pages 47 to 48). Enter the number of the program to select the cycle, with the help of the keys of the numeric keypad.

PROGRAMME 01: VOLUMETRIC FLASKS

- Prewash with hot water with the detergent
- Wash with hot water with the detergent.
- Acid rinse with the neutralizant acid
- Rinse with demineralised water
- Final rinse at 50° with demineralised water
- Drying regulated

PROGRAMME 02: BACTERIOLOGY, VIROLOGY

- Prewash with hot water with the detergent
- Wash with hot water with the detergent.
- Acid rinse with the neutralizant acid
- Final rinse at 80° with demineralised water
- Drying max.
- Cooling

PROGRAMME 03: CHEMISTRY, BIOLOGY

- Prewash with hot water with the detergent
- Wash with hot water with the detergent.
- Acid rinse with the neutralizant acid
- Rinse with demineralised water
- Final rinse at 80° with demineralised water
- Drying max.
- Cooling

PROGRAMME 04: GELOSE

- Prewash with hot water with the detergent
- Wash with hot water with the detergent.
- Acid rinse with the neutralizant acid
- Rinse with demineralised water
- Final rinse at 80° with demineralised water
- Drying max.
- Cooling

NOTE: other programs can be pre-established depending on their necessities

2.3 LAUNCHING THE CYCLE

After choosing the washing cycle number,
push on (START) button and one of the following screens will be displayed :

a) the display indicates :
- the selected cycle number,
- the temperature in the chamber,
- the current function : "PREWASH 1".

```
0 4      C Y C L E   S T A R T
  E M P T Y I N G   S T A R T
```

The cycle will be carried out without requiring any further action.

b) If the chemical container(s) are empty, the display indicates :

```
          W A R N I N G
  L A C K   O F   C H E M I C .
```

It is necessary to fill or change the detergent or acid container to start the cycle.

c) If there is water in the basin following the interruption of the previous cycle or due to abnormal addition of water, the display indicates :

```
          W A R N I N G
       F U L L   B A S I N
```

The washer will empty automatically and the cycle then proceeds normally.

d) If the temperature probe is defective, the display indicates :

F A U L T N ° 0 1
P R O B E D E F E C T

The probe must be replace prior to operation of the machine.

AT THE END OF THE CYCLE, LET COOL THE SUPPORTS, BASKETS, ACCESORIES AND WASHED OBJECTS BEFORE HANDLING THEM.

2.4 INFORMATION AVAILABLE DURING THE WASH CYCLE

BUTTON	DISPLAY	INDICATION	COMMENT
1	22 PREWASH1 Bas cuve : 37°C	Temperature at bottom of chamber	Instantaneous temperature read by the probe located in bottom of chamber
↳	03 WASH T° prog. : 70°C	Programmed temperature	Programmed temperature for phase in progress
2	03 LAVAGE T. phase : -02m42s	Remaining time of the phase	Decreasing time of a phase memorized starting from the same complete cycle already carried out
↳	03 LAVAGE T. phase : 00m53s	Past time of the phase	Past time of the phase in progress
↳	03 LAVAGE T. phase : 04m00s	Programmed time of the phase	Time programmed for the phase in progress
↳	03 WASH T. sequ. : 02m43s	Sequence duration	Past time of the sub phase (sequence) in progress
↳	03 WASH T.maxi: -1h01m28s	Maximum time remaining	Decreasing time of the cycle in progress
↳	03 WASH T.maxi: 0h04m18s	Past time	Past time of the cycle in progress
↳	03 WASH T.maxi: 1h05m32s	Maximum time	Maximum time remainder of the cycle memorized starting from the same complete cycle already carried out
3/-	03 WASH Filling	phase in progress	Name of the phase in progress
↳	03 WASH level waiting	Information on the phase in progress	Information on the progress of the phase
↳	03 WASH Chemistry Biology	Programme name	Name of the programme in progress
4/+	(no specific display)	Fast advance	Allows to skip a phase of the cycle (if selected ON in the configuration machine)
START	03 WASH R1->8 : 00000000	Relay status: 1 to 8	If test mode is activated, the display indicates status of the relays from 1 to 8
🔑	03 WASH R9 : 0	Relay status: 9	If test mode is activated, the display indicates status of the relays from 9 to 16

3.END OF CYCLE

3.1 OPENING OF THE DOORS

BURN RISK IF THE DOOR IS OPENED OVER 60°C.
AT THE END OF THE CYCLE, LET COOL THE SUPPORTS, BASKETS, ACCESORIES AND WASHED OBJECTS BEFORE HANDLING THEM.

If the chamber temperature is higher than 60°C, a prevention message appears.

E N D O F C Y C L E
H O T B A S I N > 6 0 °

The display indicates "END OF CYCLE".

E N D O F C Y C L E
O P E E N E D D O O R

Wait few seconds for unlocking device before opening the door.

3.2 OPENING

Proceed as described *page 16.*

3.3 REPRINTING OF THE TICKET

For washers equipped with the printer (option), it is possible to print the ticket again in the following cases:

- need of a second ticket
- lack of paper (end of roll)
- poor printout

Press the keys (key) and (1).

N ° ORDER TICKET
235

Each ticket is stored according to a specific ticket number.
This number (0 to 65000) is printed on ticket.
Choose with keys (4/+) or (3/-), ticket number to be printed, (0 to 65000).
Validate with the (key) key.

PRINTING
IN PROGRESS . . .

Wait for the complete impression of the ticket before launching a new washing cycle.

3.4 SWITCHING OFF

Press (⏻) to switch off the washer.
Close the water valves.
Remove and clean the basin filters (see page 52).

4.ACCESS TO USER MENU

Switch on the appliance by pressing ⏻.

The display indicates the number of the last cycle performed.

```
    P R O G R A M   n ° 0 1
  L A N C E R     x x x x L X
```

Press and hold 🔑 button for 3 seconds to validate.

```
    A C C E S S   C O D E
              - - - -
```

Enter the access code - LEVEL 1 / USER -.

If an incorrect code is entered, the following error message is displayed.

```
    A C C E S S   C O D E
  I N C O R R E C T   C O D E
```

Press and hold 🔑 button for 3 seconds to validate.

You must re-enter the correct access code.

Otherwise you access to user menu.

```
  O P E R A T O R     M E N U
P a r a m .   p r o g r a m
```

Note :

If the access code is not entered within 1 minute, the display unit returns to its initial state.

4.1 MODIFYING THE WASHING CYCLES

After accessing to user menu, you must choose **PARAM. PROGRAMME** with (4/+) and (3/-) buttons to modify the washing cycle.
Accept with (🔑) button.

```
  O P E R A T O R     M E N U
P a r a m .   p r o g r a m
```

Choose the cycle number to modify with (1), (2), (3/-), (4/+).
Accept with (🔑) button.

```
N °   o f   p r o g r a m
                1
```

if a cycle phase is programmed with a time of 00m00s that phase will be skipped when the wash cycle is executed.

Choose the time for prewash 1 : 0 to 30 mn 59 s.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.

Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.

```
1     P R E W A S H     1
R e c y c l i n g = 0 1 m 0 0 s
```

Choose water for PREWASH 1 phase: cold water mains or purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.

1 P R E W A S H 1
C o l d W a t e r m a i n s

Choose the temperature of pre-wash 1 (0 to 95° C) with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 P R E W A S H 1
T e m p . = 7 5 °

Choose the detergent intake time : 0 to 6 mn 59 s.
1 second will deliver approximately 5 ml of chemical.
Note : The volume of water in the wash chamber is approximately 13 litres.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.
Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 P R E W A S H 1
D E T E R G E N T = 0 0 m 1 2 s

Note :
Set the PREWASH 2, PREWASH 3 and WASH functions in the same way.

Select the number of running water rinses 1 (0 to 9), with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 R U N N . W A T E R 1
N U M B E R 1

Choose water for RUNNING WATER RINSE 1 phase: cold water mains or purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.

1 RUNN. WATER 1
Cold Water mains

Select the duration of the acid rinse : 0 to 30 mn 59 s.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.
Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 ACID RINSE
Recycling = 02m00s

Choose water for ACID RINSE phase: cold water mains or purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.

1 ACID RINSE
Cold Water mains

Choose the acid rinse temperature : 0 to 95°C.
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.

1 ACID RINSE
TEMP = 38 °

Choose the acid intake time : 0 to 6 mn 59 s.
1 second will deliver approximately 5 ml of chemical.
The volume of water in the wash chamber is approximately 12 litres.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.
Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 A C I D R I N S E
A C I D = 0 0 m 3 0 s

Select the number of running water rinses 2 (0 to 9), with (4/+) and (3/-) buttons. Accept with (🔑) button.

1 R U N N . W A T E R 2
N u m b r e = 0 1

Choose water for RUNNING WATER RINSE 2 phase: cold water mains or purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.

1 R U N N . W A T E R 2
C o l d W a t e r m a i n s

Select the duration of cold demin.(*) 1 : 0 to 30 mn 59 s.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.
Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.

** Demin. = demineralized, distilled or osmosis-treated water*

1 C O L D D E M I 1
R e c y c l a g e = 0 1 m 0 0 s

Choose water for COLD DEMI RINSE 1 phase: purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.



Note :
Set the COLD DEMIN.2, COLD DEMIN.3 and COLD DEMIN.4 functions in the same way.

Select the duration of the hot demin.* rinse : 0 to 30 mn 59 s.
Select the minutes with (4/+) and (3/-) buttons. Accept with (🔑) button.
Select the seconds with (4/+) and (3/-) buttons. Accept with (🔑) button.



Choose water for HOT DEMI RINSE phase: purified water
Select with (4/+) and (3/-) buttons.
Accept with (🔑) button.



Select the temperature of the hot demin.* rinse (0 to 95°C) with (4/+) and (3/-) buttons. Accept with (🔑) button.

Select the duration of drying : 0 to 90 mn.
2 minutes cooling is automatically included to this drying time (for example : 20 minutes duration = 18mn drying + 2mn cooling)
Select the minutes with 4/+ and 3/- buttons. Accept with button.
Select the seconds with 4/+ and 3/- buttons. Accept with button.

```
1        D R Y I N G
    T i m e      =   0 1 m 0 0 s
```

Select the duration of cooling : 0 to 30 mn 59 s.
Select the minutes with 4/+ and 3/- buttons. Accept with button.
Select the seconds with 4/+ and 3/- buttons. Accept with button.

```
1        D R Y I N G
P a u s e      =   0 1 m 0 0 s
```

```
    e n d   o f   m e n u
```

The display unit returns to user menu.

```
  O P E R A T O R   M E N U
R e a d i n g   p r o g r a m .
```

4.2 SEQUENCES READING OF ONE WASHING CYCLE

After accessing to user menu, you must choose **READING PROGRAM.** with (4/+) and (3/-) buttons to read the washing cycle.



Accept with (🔑) button.

Choose the cycle number to read with (1), (2), (3/-), (4/+).
Accept with (🔑) button.



The sequencing of all the functions in the cycle is displayed by pressing on (🔑) button repeatedly.

At the end of cycle, the display unit returns to user menu.



4.3 DOSING PUMP PRIMING

Once enter user menu, you must choose **"Pump Priming"** sub-menu using buttons (4/+) and (3/-).

```
O P E R A T O R   M E N U
  P u m p   p r i m i n g
```

Accept with (🔑) button.

```
        A C I D
P U M P     - >   O F F
```

Choose with button (🔑) status **"ON"** or **"OFF"** of the dosing pump. Status is "ON" during 1mn for pump flow-rate checking.

```
A C I D     =   5 8 s
P U M P     - >   O N
```

To select detergent pump output, press on button (4/+) .

```
      D E T E R G E N T
P U M P     - >   O F F
```

```
E n d   o f   r e g l a g e
```

Press button (🔑)

```
  E n d   o f   m e n u
```

4.4 NAME CHOICE OF ONE WASHING CYCLE

In addition to being identified by its number (01, 02, 03, etc.), each programmed cycle can be given a "NAME" (examples: CHEMISTRY, BACTERIO, INSTRUMENTS, ANAESTHETIC). A maximum of 16 characters is available.

After accessing to user menu, you must choose **NAME PROGRAM.** with (4/+) and (3/-) buttons to define the name of a washing cycle.
Accept with (🔑) button.

```
  O P E R A T O R   M E N U
N a m e   o f   p r o g r a m
```

Choose the cycle number to modify with (1), (2), (3/-), (4/+).
Accept with (🔑) button.

```
N °   o f   p r o g r a m
              1
```

The characters selection is got with (4/+) and (3/-) buttons.
A press on (🔑) button, enables to accept the chosen character then to pass on next space.
If the chosen name has less than 16 characters, fill-in blank space by pressing on (🔑) button.

```
N a m e   o f   p r o g r a m
□
```

When you are on the 16th character pressing (🔑) button enable to record the programme's name and to return to the user's menu.

```
    E n d   o f   m e n u
```

4.5 THE CHOICE OF MACHINE NAME

After accessing to user menu, you must choose **MACHINE NAME** with (4/+) and (3/-) buttons to define the name of the machine.
Accept with (🔑) button.

```
O P E R A T O R   M E N U
  M a c h i n e   n a m e
```

The characters selection is got with (4/+) and (3/-) buttons.
Press (🔑) button to accept the chosen character and to pass on next space.
If the chosen name has less of 16 characters fill-in empty blanks by pressing (🔑) button.

```
  M a c h i n e   n a m e
□
```

The program name is recorded in memory after the 16th character is entered by pressing the (🔑) button and to return to the user's menu.

```
  E n d   o f   m e n u
```

4.6 READING OF CYCLE FAULTS

After accessing to user menu, you must choose **FAULT CYCLES** with (4/+) and (3/-) buttons to read the 5 last faults.

Accept with (🔑) button.

O P E R A T O R M E N U
F A U L T Y C Y C L E S

Example :

P t r : 0 A l a r m : 8
P R E S S O S T A T F A U L T

Change the Ptr value with (4/+) and (3/-) buttons. You could like this read the N° and the designation the alarm previously tripped. If you select the value "0" you got the last tripped alarm, if you select the value "-1" you got the last before alarm, etc…

If you press (START) button, you will get any additional information about the alarm tripping.

To quit this menu, press (🔑) button.

4.7 PRINTER PARAMETERS (OPTION)

This menu allows to customize 2 heading lines and 3 foot lines on the ticket (if printer option).

```
O P E R A T O R   M E N U
P r i n t e r   p a r a m .
```

Accept with (🔑) button.

```
H e a d   1 :   e n t e t e   d
u   t i c k e t   l i g n e   1
```

First character is flashing on top of display.

Characters are selected with the (4/+) and (3/-) keys or numeric keypad.

Each character must be validated with the key(🔑).

When the ticket line is customized, complete the line of characters with successive pressings on key (🔑).

Press on key (🔑) to go to next heading line then to foot lines.

Accept with (🔑) button.

```
E n d   o f   m e n u
```

The display returns to the user's menu.

4.8 RETURN TO THE INITIAL STATE

To quit the user menu, you must, choose **END OF SETTING ?** with (4/+) and (3/-) buttons.

Accept with (🔑) button.

5.TABLE OF FACTORY-PROGRAMMED CYCLES – 810 LX

The washer is supplied with 4 factory-programmed cycles that are designed to meet most washing needs. However, all cycles can be modified to meet customer requirements.

Water consumption estimated per phase (depends on the baskets/racks used): 12 litters.
Output from acid and detergent pumps (depends on the chemicals used) : 280 ml/min.

		Volumetric Flasks	Bacterio. Virology	Chemistry Biology	Agarose Gel
SEQUENCES	**POSSIBILITIES**	**PROG. 01**	**PROG. 02**	**PROG. 03**	**PROG. 04**
PREWASH TIME 1	0 to 30 mn	1	2	2	2
FILLING	CWM / HWM / PW	HWM	HWM	HWM	HWM
PREWASH 1 TEMPERATURE	0 to 95 °C	0	0	0	90
PREWASH 1 DETERGENT	0 to 360 s	12	12	12	30
PREWASH TIME 2	0 to 30 mn	0	0	0	1
FILLING	CWM / HWM / PW	/	/	/	HWM
PREWASH 2 TEMPERATURE	0 to 95 °C	/	/	/	0
PREWASH 2 DETERGENT	0 to 360 s	/	/	/	0
PREWASH TIME 3	0 to 30 mn	0	0	0	0
FILLING	CWM / HWM / PW	/	/	/	/
PREWASH 3 TEMPERATURE	0 to 95 °C	/	/	/	/
PREWASH 3 DETERGENT	0 to 360 s	/	/	/	/
WASH TIME	0 to 30 mn	4	4	2	2
FILLING	CWM / HWM / PW	HWM	HWM	HWM	HWM
WASH TEMPERATURE	0 to 95 °C	50	85	70	90
WASH DETERGENT	0 to 360 s	30	30	30	36
RUNNING WATER RINSE 1	0 to 9	1	1	2	2
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
ACID RINSE TIME	0 to 30 mn	2	2	2	2
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
ACID RINSE TEMPERATURE	0 to 95 °C	0	0	0	0
NEUTRALIZING ACID	0 to 360s	30	30	30	30
RUNNING WATER RINSE 2	0 to 9	1	2	1	1
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
COLD DEMI. TIME 1	0 to 30 mn	1	0	1	1
FILLING	PW	PW	/	PW	PW
HOT DEMI. TIME	0 to 30 mn	1	1	1	1
FILLING	PW	PW	PW	PW	PW
HOT DEMI. TEMPERATURE	0 to 95 °C	50	80	80	80

6.TABLE OF FACTORY-PROGRAMMED CYCLES - 815LX

The washer is supplied with 4 factory-programmed cycles that are designed to meet most washing needs. However, all cycles can be modified to meet customer requirements.

Water consumption estimated per phase (depends on the baskets/racks used): 12 litters.
Output from acid and detergent pumps (depends on the chemicals used) : 280 ml/min.

		Volumetric Flasks	Bacterio. Virology	Chemistry Biology	Agarose Gel
SEQUENCES	**POSSIBILITIES**	**PROG. 01**	**PROG. 02**	**PROG. 03**	**PROG. 04**
PREWASH TIME 1	0 to 30 mn	1	2	2	2
FILLING	CWM / HWM / PW	HWM	HWM	HWM	HWM
PREWASH 1 TEMPERATURE	0 to 95 °C	0	0	0	90
PREWASH 1 DETERGENT	0 to 360 s	12	12	12	30
PREWASH TIME 2	0 to 30 mn	0	0	0	1
FILLING	CWM / HWM / PW	/	/	/	HWM
PREWASH 2 TEMPERATURE	0 to 95 °C	/	/	/	0
PREWASH 2 DETERGENT	0 to 360 s	/	/	/	0
PREWASH TIME 3	0 to 30 mn	0	0	0	0
FILLING	CWM / HWM / PW	/	/	/	/
PREWASH 3 TEMPERATURE	0 to 95 °C	/	/	/	/
PREWASH 3 DETERGENT	0 to 360 s	/	/	/	/
WASH TIME	0 to 30 mn	4	4	2	2
FILLING	CWM / HWM / PW	HWM	HWM	HWM	HWM
WASH TEMPERATURE	0 to 95 °C	50	85	70	90
WASH DETERGENT	0 to 360 s	30	30	30	36
RUNNING WATER RINSE 1	0 to 9	1	1	2	2
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
ACID RINSE TIME	0 to 30 mn	2	2	2	2
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
ACID RINSE TEMPERATURE	0 to 95 °C	0	0	0	0
NEUTRALIZING ACID	0 to 360s	30	30	30	30
RUNNING WATER RINSE 2	0 to 9	1	2	1	1
FILLING	CWM / HWM / PW	CWM	CWM	CWM	CWM
COLD DEMI. TIME 1	0 to 30 mn	1	0	1	1
FILLING	PW	PW	/	PW	PW
HOT DEMI. TIME	0 to 30 mn	/	3	3	3
FILLING	PW	PW	PW	PW	PW
HOT DEMI. TEMPERATURE	0 to 95 °C	0	80	80	80
DRYING TIME	0 to 90 mn	/	25	25	25
DRYING	0 to 110°C	/	100	100	100
PAUSE	0 to 30 mn	0	5	5	5

(*) : *The programmation of the hot water demineralized involve automatically a drying and cooling period phase with fixed parameters. (see above the values in the table).*

CHAPTER 4 TRACEABILITY

These last years, TRACEABILITY has become a crucial issue. The matter is to control permanently the correct development of the washing cycle and to obtain its validation.

TRACEABILITY enables the supervision of the correct performance of parameters such as washing, chamber filling, detergent taking, effective temperature, duration of the phases.

During the development of the program all the data must be registered, archived in paper support.

1.EXTERNAL PRINTER (OPTION)

ITS ROLE:

The LANCER PRINTER gives permanently the development of the washing.

Also, it permits the stock of the information.

ITS RESULTS:

At the end of the program, the results are registered and archived, whether on a paper support by the mean of an horodated ticket.

EXTERNAL PRINTER

(desktop printer)

CHAPTER 5 MAINTENANCE OF THE WASHER

This chapter describes the maintenance operations to assure the good working of your washer.

Residues of products such as acetone, solvents, petroleum, petroleum derivatives, chromium sulphate, acid (sulphuric, nitric, hydrochloric even at a low concentration), must not be used or placed in the washer in any circumstances.

1. FILTERS

1.1 STRAINERS FILTERS

Check the cleanness of the strainer filters and clean them if needed.



1.2 CHAMBER FILTERS

This two filters prevent the residues to enter the hydraulic circuit.



A	PUMP SUCTION FILTER
B	CHAMBER BOTTOM FILTER

Do not forget to clean the filters after each cycle.
If you regularly do not clean the filters, the performances of your machine are likely to be affected for it.

DO NOT FORGET TO REPLACE THE FILTERS BEFORE LAUNCHING A WASHING CYCLE

2. SHUT DOWN AT END OF DAY

SHUT OFF THE WATER INLET COCKS so that the valves are not left pressurised.
Do not forget to open them again before using the appliance.

3.EXTERNAL MAINTENANCE OF THE WASHER

LANCER washers are entirely covered with panels (bodywork) in stainless steel AISI 304L.

3.1 CLEANING METHOD

The periodic maintenance cleaning must be done with a cleaning product.

Should the periodic maintenance have been largely forgotten, we recommend the use of a specific cleaning product.

The product must be applied with the help of a rag or a soft sponge, and always polishing the stainless steel in the sense of the brushing to avoid the risk of stripes.

For the drying, the best is using a rubber scraper similar to the one used to clean windows. This will avoid watering you can have with a rap cleaning.

PRUDENCE:
TRY TO AVOID THE PROJECTIONS OF LIQUID OVER THE WASHER.

3.2 CLEANING PRODUCTS

LANCER offers a maintenance product for stainless steel in the market under the name of LANCERSHINE.

A safe and efficient aerosol cleaning product for a use in the external side of the stainless machines and other equipments to be washed, assuring a very professional finishing.

Available in container of 450 ml. Ref: LANCERSHINE

DETERGENTS, SOAPS:

All the detergents, soaps or cleaning products found in shops can normally be used, but they MUST NOT contain chlorinated products. Domestic soaps for dishwashers or washing machines are particularly adapted to the periodical cleaning.

ABRASIVE DUSTS:

These products can stripe the stainless steel surfaces and modify then the aspect, at least locally. Even that, their use can be useful to eliminate by scraping the adherent spots.

ACID PRODUCTS:

The resource to these acid-cleaning products must only be used in specific cases.

Vinegar (acetic acid) can be used to remove stains left by minerals.

There are phosphoric acid-based or nitric acid-based products specially conceived for the cleaning of stainless steels. It is convenient to follow strictly the instructions given by theirs manufacturers.

The chloric disinfectants must only be used with caution: diluted solution in cold water, short contact time, abundant rinsing.

IN ALL THE CASES IT IS NECESSARY TO PROCEDE AFTER THE CLEANING TO AN ABONDANT AND CAREFUL RINSING (WITH A SOFT TEXTILE), IN ORDER TO ELIMINATE EVERY TRACE OF THE USED PRODUCT.

4.DECONTAMINATION OF THE MACHINE AND PARTS

4.1 WHEN TO DECONTAMINATE THE WASHER ?

Special care must be taken to protect users and maintenance personnel from coming in contact with the chemicals, temperatures, and hazardous materials that may be used in this machine. This can occur due to a wash cycle being prematurely interrupted by opening the door, turning off power, or an alarm condition.

If the door has been inadvertently opened, the machine should be allowed to cool down for one hour then the door should be shut and the cycle restarted. If the power has been inadvertently turned off, it should be turned on and the cycle restarted.

If the washer has stopped due to an alarm condition that requires a maintenance technician, the maintenance technician must decontaminate the machine before performing the repairs.

4.2 HOW TO DECONTAMINATE THE MACHINE ?

Press ⏻ key to switch the washer off.

The machine should be allowed to cool down for one hour.

Use the necessary personal protection (gloves, mask, safety glasses…).

Remove the Waste Water Flexible emptying hose from the standpipe and place it in a large containment sump (that can hold 14 litres (3.7 gallons)) with a top edge no more that 100 mm (4 inches) above the floor. This will siphon water from the basin into the containment sump.

Replace the Waste Water Flexible emptying hose into the standpipe.

Remove the 2 basin filters and use an external pump to remove the remainder of the water from the bottom of the chamber. Replace the 2 basin filters.

Remove the necessary side panel(s) in order to gain access to the components that need to be repaired or replaced.

Perform the repairs by replacing the parts in the same manner by which they were installed in the factory. Please note that all safety devices on this machine are factory preset and will not require any modification or calibration by maintenance personnel.

Replace the side panel(s) that were removed.

Press ⏻ key to switch the washer on.

Dispose of used parts that may have been exposed to toxic chemicals or contaminated by pathogenic materials according to local and company regulations. Please consult the Material Safety Data Sheet for specific information regarding the chemicals used in this machine.

5.PREVENTIVE MAINTENANCE

LANCER'S TECHNICAL ASSISTANCE SERVICE recommends to all the users at least one annual preventive maintenance visit.

The preventive maintenance reduces the risks of stops of the washer due to breakdowns and enables enlarge the life duration of the equipments.

Depending on the countries where the washer is used and the local norms, a higher frequency of preventive maintenance visits can be necessary.

6.PREVENTATIVE MAINTENANCE SCHEDULE

FUNCTION	Daily	Biannual	1 Year	2 Year	5 Year
CLEAN FILTER SYSTEM IN CHAMBER.	X	X	X	X	X
CHECK CHEMICAL CONTAINERS FOR ANY LEAKAGE.	X	X	X	X	X
ENSURE CHEMICAL HOSES ARE NOT PINCHED.	X	X	X	X	X
CLEAN EXTERIOR PANELS.	X	X	X	X	X
INSPECT WATER SUPPLY HOSES FOR CRACKS, BULGES, AND LEAKS.		X	X	X	X
ENSURE THE WATER HOSE SEALS AND FILTERS ARE CLEAN AND HAVE NO CRACKS.		X	X	X	X
CHECK CHEMICAL SUPPLY HOSES FOR CRACKS, BULGES AND LEAKS.		X	X	X	X
INSPECT INTERNAL TUBING ON CHEMICAL PUMPS FOR WEAR. (IF APPLICABLE)		X	X	X	X
CHECK CHEMICAL LEVEL SENSORS FOR CORRECT OPERATION. (IF APPLICABLE)		X	X	X	X
ENSURE ALL PANELS ARE PROPERLY SECURED.		X	X	X	X
CHECK ALL INTERNAL HOSES FOR CRACKS, BULGES AND LEAKS.		X	X	X	X
ENSURE ALL HOSE CLAMPS ARE PROPERLY TIGHTENED.		X	X	X	X
CHECK ALL COLUMN SEALS FOR LEAKS AND CRACKS.		X	X	X	X
CHECK SPRAY ARM SUPPORT SEALS FOR LEAKS AND CRACKS.		X	X	X	X
CHECK SPRAY ARMS AND BUSHINGS FOR WEAR.		X	X	X	X
CHECK DOOR SEAL AND GASKET FOR LEAKAGE.		X	X	X	X
INSPECT THE DOOR SPRINGS, DOOR WHEELS AND THEIR SLING, HOOKS, DOOR SWITCH FOR PROPER OPERATION.		X	X	X	X
CHECK RECYCLING AND EMPTYING PUMP SEALS FOR LEAKAGE AND QUIET OPERATION.			X	X	X
CHECK FOR LOSE ELECTRICAL CONNECTIONS AT COMPONENTS AND ELECTRONIC CARDS.			X	X	X
VERIFY THE CORRECT OPERATION OF ALL RELAYS AND THEIR ASSOCIATED COMPONENTS.			X	X	X
CHANGE THE HEATING RELAY.					X

(1) Daily maintenance must be handled by users staff.
(2) Others maintenances (bi-annual, 1 year, 2 years & 5 years) must be carry out by the Lancer's technical assistance service.

7.RECOMMENDED SPARE PARTS 810 LX – 815 LX

Description	New Part #	Quantity / Machine
Door Spring	12010003	2
Door wheels	46020064	2
Door sling	46040004	2
Emptying Pump 50 hz	23010047	1
Emptying Pump 60hz	23010070	
Pressurestat	28020066	1
Autoclude™ Internal tubing	23080014	2
Main Pump50hz	23010076	1
Main Pump60hz	23010074	
capacitor	23080098	1
Door Seal	14050003	3
Bottom Door Seal	04120002	1
Column Seal	14030041	2
Threaded Connection	33080026	2
Water Inlet Filter/Seal	17010025	2
Spray Arm Washer	31040012	2
Heating Relay	20030007	1

CHAPTER 6 PROBLEMS

In this chapter you will get all the problems that you might get on your washer.

In a general way and whatever the noted anomaly, it is appropriate to stop the machine, to disconnect the power supply cable and to turn off the taps of water arrivals.

1. INCIDENTS

1.1 THE DETERGENT OR NEUTRALIZING AGENT DOES NOT ENTER THE WASHER

- The tube is blocked.
- The tank is empty.
- The pump hose is pinched.

1.2 THE WASHER DOES NOT FUNCTION

- It is not connected to the power supply.
- There is mains power.
- The circuit-breaker protecting the electrical control circuit has been tripped. CONSULT THE TECHNICAL DEPARTMENT.

1.3 ABNORMAL NOISE

- One of the washing arms is touching one or more of the items to be washed.
- Check the loading of the washer.

EVERY MAINTENANCE AND TECHNICAL INSTALLATION INTERVENTION MUST BE DONE BY A TECHNICIEN ENTITLED TO WORK UNDER TENSION.

2. WARNINGS

2.1 - LACK OF PRODUCTS

W A R N I N G
L A C K O F C H E M I C .

Lack of product definition : The following message is displayed at the start of the cycle when you press the START key.

Corrective Action :Check level of additive tanks, replace additive low level tank.

2.2 HOT CHAMBER

W A R N I N G !
H O T C H A M B E R

INCIDENT: the following message is displayed if the temperature inside the washing chamber is above the safety temperature set point for door opening.

ACTION: At the end of the cycle, let the washer chamber and contents cool before opening the chamber door.

2.3 FULL BASIN

W A R N I N G !
F U L L B A S I N :

INCIDENT: If the wash chamber contains water at the beginning of the cycle, either from the interruption of the previous cycle or due to an abnormal addition of water to the chamber.

ACTION: The washer is automatically emptied and the cycle then proceeds normally.

2.4 MAINTENANCE REMINDER



INCIDENT: After turning on the machine, the reminder of the upcoming preventative maintenance is shown on the display.

ACTION: Press the (START) key to acknowledge the reminder. Schedule a preventative maintenance service call.

2.5 PREVENTATIVE MAINTENANCE REQUIRED



INCIDENT: After starting the wash cycle, the preventative maintenance message is shown on the display.

ACTION: Press the (START) key to acknowledge the reminder. Preventative maintenance should be performed on the machine.

3.FAULT ALARMS

These alarms stop the operation of the washer. To clear the alarm mode, the washer must be switched off by pressing ⏻ button.

3.1 FAULT N°1 PROBE FAULT.

F A U L T N ° 0 1
P R O B E D E F E C T

Probe Fault Definition :
The probe used to check the temperature of the water in the chamber is disconnected or defective.

Corrective Action :
CONTACT A MAINTENANCE TECHNICIAN to check the electrical connection and the condition of the probe.

3.2 FAULT N°2 EMPTYING FAULT.

F A U L T n ° 0 2
E M P T Y I N G F A U L T

Emptying Fault Definition :
The washer has not been fully emptied at the end of the normal emptying time defined in the Common Times menu.

Corrective Action :
Check that there is no restriction on the emptying line, that the emptying pump (or the valve) and its pipes are not blocked and that the chamber filters are not clogged.

This message may be displayed at the end of PREWASH 1, PREWASH 2, WASH, RUNNING WATER RINSE 1, ACID RINSE, RUNNING WATER RINSE 2, COLD DEMI. WATER RINSE and HOT DEMI. WATER RINSE.

3.3 FAULT N°3 HEATING EXCESS.

F A U L T n ° 0 3
H E A T I N G E X C E S S

Heating Excess Definition :
Is displayed if the basin temperature exceeds the programmed temperature by 20°C.

Corrective Action :
Verify that the incoming water temperature does not exceed the programmed setpoint temperature.
CONTACT A MAINTENANCE TECHNICIAN.

3.4 FAULT N°4 HEATING FAULT.

F A U L T n ° 0 4
H E A T I N G F A U L T

Heating Fault Definition :
This message is displayed during one of the heating phases if the water temperature has not increased after 8 minutes of heating duration.

Corrective Action :
CONTACT A MAINTENANCE TECHNICIAN TO CHECK :
- the electrical connections,
- the condition of heating elements,
- the safety thermal cut-out with manual reset.

This message may be displayed during the heating phase of PREWASH 1, PREWASH 2, WASH, and HOT DEMI. WATER RINSE.

3.5 FAULT N°5 NO WATER.

F A U L T n ° 0 5
N O W A T E R

No Water Definition :
The washer did not reach the required water level by the end of the normal filling time defined in the Common Times menu.

Corrective Action :
Check that the water inlet valves are open, that the water inlet pipes are in good condition and that the water inlet filters are clean.

This message may be displayed during filling for PREWASH 1, PREWASH 2, PREWASH 3, WASH , RUNNING WATER RINSE 1, ACID RINSE, RUNNING WATER RINSE 2, COLD DEMI. WATER RINSES and HOT DEMI. WATER RINSE.

3.6 FAULT N°6 DOOR FAULT

F A U L T N ° 0 6
O P E N E D D O O R

Door Fault Definition :
It displays when the door is opened during the cycle. The cycle is stopped.

Corrective Action :
Shut the door and start the cycle again.

3.7 FAULT N°7 LEVEL FAULT.

F A U L T N ° : 0 7
F I X T O L E V E L

Fix to Level Definition :
After achieving the proper water level during the Filling Time, the water level has dropped causing the pressurestat to open times to indicate fluctuation of the water level in the machine.

Corrective Action :
Check if you have a leak or if the emptying tube is out of location.

3.8 FAULT N°8 PRESSURESTAT FAULT.

F A U L T N ° : 0 8
P R E S S O S T A T F A U L T

Pressostat Fault Definition :
The pressurestat has a N.O. + N.C. contact. This alarm indicates that the contacts are both closed or both open at the same time which is not correct.

Corrective Action :
Check the state of the pressurestat

Pictures and drawings non contractual.LANCER reserves the right to make changes in this manual

LANCER

advanced washing & disinfection solutions

LANCER - 30 bd. de l'Industrie - Z.I. PAHIN - 31170 Tournefeuille - FRANCE - Phone: +33 (0)5 61 15 11 11 - Fax.: +33 (0)5 61 15 16 16
Site: www.lancer.fr - France E-mail: lancersite@lancer.fr - Export E-mail: lancerexport@lancer.fr

LANCER USA INC.
3543 State Rd 419 - Winter Springs, Fl 32708 USA
Phone: +1 407 327 8488 Fax: +1 407 327 1229
Site: www.lancer.com - E-mail: sales@lancer.com

LANCER UK LTD.
1 Pembroke Avenue Waterbeach - Cambridge CB5 9QR - UK
Phone: +44 1 223 861 665 Fax: +44 1 223 861 990
Site: www.lancer.co.uk - E-mail: sales@lancer.co.uk